

Pinnacle Ski Club, Ohakune Lodge, “Power On” Procedure

If the lodge has been un-occupied for a while, it is likely the lodge power is switched off.

To “Power On” the lodge do the following:


- 1) Access the lodge by entering your passcode into the electronic lock




- 2) From the hallway turn left to access the workshop.



3) Within the workshop locate and open the switchboard



4) Switch on the power using the **lower right switch**



5) If you are the last guest to leave, please switch off the power using the same **lower right switch**