


Turn on/off power and water at Pinnacle Ski Club Whakapapa

If the Whakapapa lodge has been empty for a while it's likely the power and water is switched off.

To turn on follow this procedure:

1. Enter the lodge door with your unique door code combination.
2. Walk through the entranceway / workshop, to the basement door.
3. On the adjacent wall, through the basement door, is the main switch and fuse board.
4. If the "Main Switch" (shown by arrow) is in the **off** position, then turn **on**.



5. If the water is switched off follow the water on/off procedure found inside the pump cupboard door (cupboard found under the stairs)

6. When existing the lodge please turn the power off at the “**Main Switch**” denoted by the arrow